28 **5.0 FINISHING**

ΕN

RISK OF FIRE!

NEVER OBSTRUCT THE FRONT OPENING OF THE APPLIANCE.

DO NOT STRIKE, SLAM OR SCRATCH GLASS. DO NOT OPERATE APPLIANCE WITH GLASS REMOVED, CRACKED, BROKEN OR SCRATCHED.

5.1 HOUSING PANEL INSTALLATION

- A. Secure the housing panels as illustrated using the 17 #8 X 3/8" screws supplied.
 - 4 screws secure the top housing panel.
 - 3 screws secure the bottom housing panel.
 - 5 screws secure each of the side housing panels.

5.2 DOOR REMOVAL / INSTALLATION



GLASS MAY BE HOT, DO NOT TOUCH GLASS UNTIL COOLED.


THE DOOR LATCHES ARE PART OF A SAFETY SYSTEM AND MUST BE PROPERLY ENGAGED. DO NOT OPERATE THE APPLIANCE WITH LATCHES DISENGAGED.

FACING AND/OR FINISHING MATERIALS MUST NOT INTERFERE WITH AIR FLOW THROUGH AIR OPENINGS, LOUVRES OPENINGS, OPERATION OF LOUVRES OR DOORS OR ACCESS FOR SERVICE. OBSERVE ALL CLEARANCES WHEN APPLYING COMBUSTIBLE MATERIALS.

BEFORE DOOR IS REMOVED TURN THE APPLIANCE OFF AND WAIT UNTIL APPLIANCE IS COOL TO THE TOUCH. DOORS ARE HEAVY AND FRAGILE SO HANDLE WITH CARE.

- A. Remove the surround. (see "SURROUND INSTALLATION/REMOVAL" section) then remove the safety screen, (see, "SAFETY SCREEN INSTALLATION/REMOVAL" section).
- **B.** Remove the 3 screws that secure the door.
- **C.** Lift the door up and off.
- **D.** Reverse steps to reinstall the door, safety screen and surround.

NOTE: A barrier designed to reduce the risk of burns from the hot viewing glass is provided with the appliance and must be installed.



72.4